

# Skyline<sup>®</sup> Knit Fabric Care and Cleaning – Includes Superfecta<sup>®</sup> -568 and Poly Stretch -570



## General Fabric Handling – Includes WindScape<sup>®</sup>, DesignView<sup>®</sup>, Fabric Structures, Envoy<sup>®</sup>, PictureScape<sup>®</sup>, Table Throws and Exalt<sup>®</sup> and Podium Case Table Fabric Covers

- Handle fabric in a clean area with clean hands. Products come with a drop cloth and white gloves for use during installation and dismantle.
- Never put fabric away while it is damp.
- Zip fabric cover and fold small enough to fit into nylon storage bag. Keep storage bag for future use.
- If fabric becomes wrinkled, use Skyline Fabric Steamer or cool iron on opposite side of graphic.

### Helpful Stain Treatment Hints

- Treat stains as soon as possible for best results.
- Try removing stains with water alone before using cleaning products, as cleaning products can sometimes leave a residue or help the stain to set in.
- If possible, remove fabric from frame before beginning treatment. Marking the stain with a piece of tape while it is on the frame will make it easier to find it after fabric is removed.
- When possible, treat from the back side of the stain, especially when caused by oil.

### Stain Treatment

- Remove as much built up staining material as possible. Tape is recommended for loose, dry material such as dirt.
- When using water alone, apply it to the back side of the stain and dab material from the back while stretching fabric. Use minimal amounts of water so as not to cause water stains or make the stain area larger.
- Using a white cloth, dab stained area from the outside edges inward to avoid spreading the stain.
- When using a cleaning agent, be sure to rinse the area thoroughly with water to prevent residue stains.

### Washing or Dry Cleaning vs. Spot Cleaning

- If fabric does not have magnet, extrusions or other hardware attached it can be dry cleaned or machine washed using mild soap and cool heat or no heat to dry. (zippers and grommets are acceptable to wash). An industrial washing machine may be necessary for large size fabric.
- Fabric and liners if applicable must be completely dry before packaging.

**Warning:** Washing in warm to hot water, or using warm to hot heat, can cause the fabric to shrink. Fabric can develop mold if packaged damp.

The chart below reflects our recommendations based upon testing of 13 cleaning products on dirt, grease, oil and ink.

GUIDE FOR USE WITH SUPERFACTA <sup>®</sup> FABRIC GRAPHIC COVERS			
Printed Graphic Cover – Superfecta <sup>®</sup> or Poly Stretch fabric			
Any Spot – Start with	Dirt and Grease	Oil*	Ink
1. Water 2. Soap and Cool Water 3. Baby Wipes	Clorox Oxi Magic	Shout Wipes Plus	Baby Wipes

\* For best results, treat oil from the back side of the stain.

**No expressed or implied warranty is intended.** This information is provided to assist you with the care and maintenance of your Skyline product. Skyline does not warrant against the staining of your fabric product or inability to remove stains should they occur. Skyline Displays, Inc. in no way endorses one cleaning product over another. The grid provided merely reflects our test results.

## Certificate of Fabric Flame Retardancy

Certificate Date: August 1, 2009

Skyline Exhibits warrants that the fabrics used in this exhibit, described in the list below, have been certified by the manufacturer or supplier as being treated with fire retardant chemicals such that:

- The material has been independently tested and shown to meet or exceed the minimum requirements of the NFPA 701 small scale test (test 1). The NFPA 701 small scale test meets or exceeds requirements stated in the following fire codes:
  - 1997 Uniform Fire Code (section 1103.3.3.2)
  - 2003 NFPA 1 (section 8.1.2.3.2)
  - 2003 NFPA 101 (section 10.3)
  - 2003 International Fire Code (section 805.1-2)
  - 1999 BOCA Fire Code (section 805.1-2)
  - Ontario Fire Code O. Reg. 388/97 (section 2.3.2.1 and 2.3.2.2)
- For fabrics with images using the dye sublimation process, the toner manufacturer states, “the dye sub inks will not affect the fire retardant properties of the fabric provided it has gone through the heat press for sublimation.”

Copies of the manufacturer/supplier certification to the above standards are on file at Skyline Exhibits, St. Paul, Minnesota and copies are available by calling 1-800-328-2725 or by contacting any Skyline dealer. Visit [www.skyline.com](http://www.skyline.com) to locate a local Skyline dealer office.